



**DECIBEL**  
SOUND SOLUTIONS

**DJ CONTROLLER / CDJ & DJ MIXER SETUP TO PA SYSTEM.**  
This step-by-step guide will assist you with the setup of DJ decks/  
controller to our PA system (active speakers).



**Step 1 –**

Before any XLR cables and power cables are connected ensure all main power on DJ decks/controller and speakers are turned off and volume turned down. Green LED light 'power' on speaker should be turned off.



# DJ CONTROLLER / CDJ & DJ MIXER SETUP TO PA SYSTEM.

This step-by-step guide will assist you with the setup of DJ decks/controller to our PA system (active speakers).

**Step 2** - Connect 2x XLR cables (female side - image attached) or RCA/XLR cable to 'Master output' of DJ decks/controller, followed by male side of XLR cables connect to back of the speaker input. (labelled 1MIC/LINE INPUT)



Speaker Input 1. connect male end of the XLR cable here

XLR Cable.

Female End

XLR Cable.

Male End



Master Outputs. Connect the female end of the XLR cable to either Left or Right & do the same with the opposite speaker.



**DJ CONTROLLER / CDJ & DJ MIXER SETUP TO PA SYSTEM.**  
This step-by-step guide will assist you with the setup of DJ decks/  
controller to our PA system (active speakers).

**Step 3** - Connect power leads to  
the back of the DJ decks/controller and back of the speakers.



**Speaker Power Input.**  
Connect power cable  
here



**CDJ Power Input.**  
connect power  
cable here




**DJ Mixer Power Input.**  
Connect power cable here  
make sure power button  
is in the off position.

**IMPORTANT.**  
Please ensure  
all equipment is powered  
off before connecting  
power cables



## DJ CONTROLLER / CDJ & DJ MIXER SETUP TO PA SYSTEM.

This step-by-step guide will assist you with the setup of DJ decks/controller to our PA system (active speakers).



### Speaker Stands Setup Guide

**Step 1-** Turn knob anti clockwise to loosen up the grip before pulling 3 stand legs apart. Ensure the legs are a safe and suitable distance before tightening knob back clockwise. Make sure legs are a suitable distance apart for speaker to be placed on top without them falling over.

**Step 2-** After extending stand pole to desired position (ideally 1st or 2nd hole). Make sure to place silver pin (See in image attached) through hole before turning knob back clockwise to tighten. Stands should now be all setup and secure!

**IMPORTANT.**

**STAND LEGS**  
Pull safe distance apart  
and tighten knob